

Saturn

Laminate

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. Do not use any abrasive cleaners.

Powder-Coated Metal

Gently wipe off any spill or debris. After, dip a lint-free cloth into a mild soap and water mixture. Scrub gently over the stained area. Do not use any abrasive cleaners.