

6D Adjustable Arms #22ACB/#22ACG



Arm Height (Up/Down)

Type: Button

Press the button found beneath the armrest while grasping the armrest with both hands. Raise or lower each arm to desired height. Release the button.

Armrest In/Out

Type: Armrest

Using both hands, push the armrest in or out (left/right) to desired position to increase or decrease space between arms. Adjust each armrest separately.

Armrest Rotation In/Out

Type: Armrest

While sitting in the chair, grasp the armrest and rotate in or out to desired angle. Adjust each armrest separately or at the same time.



< Watch our 22ACB/22ACG
Online User Guide