


## Basic Conference & Seat Depth #26C



**Single Position Back Lock** 

Type: Pull paddle

Use the same paddle you used for the seat height adjustment. To lock the chair in an upright position, shift your weight forward until the chair is in an upright position, then push lever in. To rock (free float) shift your weight forward and pull the lever out.

Seat Depth #12SS Type: Pull paddle

Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

