

Auto-Adjust Body Balance #74C



4-Position Tilt Limiter

Type: Rotatable knob

Rotate the outer dial for three separate tension settings. Rotate clockwise (forward) to increase tension & counter-clockwise (backward) to decrease tension.

Optional Seat Depth #12SS

Type: Pull paddle

Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 74C
Online User Guide



Watch our 74C-12SS >
Online User Guide