

Adjustable Mechanical Lumbar #12LUM



Lumbar Depth Adjustment

Type: Turn knob

Turn the knob clockwise (forward toward front of chair) to increase lumbar support, pushing the lumbar cushion forward into the back. Turn the knob counter-clockwise (backward toward back of chair) to decrease lumbar support, moving the lumbar cushion away from the back. This adjustment is made from a seated position.



< Watch our 12LUM
Online User Guide