


LR2/LR2G Run II adjustable lumbar support.

Optional on all Run II mesh backs.



1 Lumbar position adjustment - - From the seated position, use a hand to make adjustments by engaging the small, black lumbar adjustment lever. Slide the lever up to move the lumbar support up. Slide the lever down to move the adjustable lumbar support down.

Lift up = lumbar up.

Lift down = lumbar down.



Contract Holder

contract #: GS-28F-005CA

contractor: VIA INC