

Onda

Control Mechanisms:

- Auto-Adjust Body Balance #74C
- Quick Adjust Advanced Synchro #67C
- Stool: Auto-Adjust Body Balance #35C

Adjustable Arms:

- 6D Adjustable Arms #ONA1/#ONA2

Adjustable Lumbar:

- Adjustable Lumbar #OLUM1/OLUM2



Auto-Adjust Body Balance #74C



4-Position Tilt Limiter

Type: Rotatable knob

Rotate the outer dial for three separate tension settings. Rotate clockwise (forward) to increase tension & counter-clockwise (backward) to decrease tension.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 74C
Online User Guide

Quick Adjust Advanced Synchro #67C



Back Tension

Type: Turn dial on paddle

Rotate knob right to increase tilt tension.
Rotate knob left to decrease tilt tension.

Seat Depth #SS

Type: Pull paddle

Push down on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back. This option is always included on the 67C control on an Onda chair.

5-Position Tilt Limiter

Type: Turn dial

To recline more, turn the dial right.
To recline less, turn the dial left.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

Optional Forward Tilt #FT

Type: Pull paddle

Push the paddle in the down position and lean back in the chair. You will hear a click when the forward tilt mechanism has turned on. To turn off the forward tilt feature, lift the paddle in the up position and lean back in the chair. You will hear a click when the forward tilt mechanism has turned off.



< Watch our 67C-SS
Online User Guide



Watch our 67C-SS-FT >
Online User Guide

Stool: Auto-Adjust Body Balance #35C



3-Position Tilt Limiter

Type: Rotatable knob

Rotate the outer dial for three separate tension settings. Rotate clockwise (forward) to increase tension & counter-clockwise (backward) to decrease tension.

Foot Ring #11DR & #11XDR

Type: Footrest

Press down on the plastic inner hub and lift the foot ring up to unlock. Adjust to desired position. To lock, press down on the outer foot rest until hub is in locked position.

Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 35C
Online User Guide

Watch our Foot Ring >
Online User Guide



6D Adjustable Arms #ONA1/#ONA2



Arm Height (9-Position)

Type: Arm

Lift the arm to the desired height. To lower, pull up to unlock & then lower to the desired height. Locks in 1 of 9 positions.

Armrest Back/Forth

Type: Armrest

Grasp armrest & slide it forward or back to desired position.

Armrest In/Out

Type: Button

Press the button on the side of the armrest to release the armrest. Can rotate a full 360° around and lock into 1 of 6 positions.



< Watch our ONA1/ONA2
Online User Guide

Adjustable Lumbar #OLUM1/OLUM2



Vertical Lumbar Position

Type: Handles

From a seated position, reach behind to the back and grasp the tabs on either side of the lumbar support with both hands. Squeeze and lift the lumbar support up or down.



< Watch our OLUM1/OLUM2
Online User Guide