


**64CS** Run II stool control user guide.

For use on Run II high & mid backs with medium seats.



**1** Seat height adjustment - Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

**2** Back tension adjustment - Rotate knob right to increase tilt tension. Rotate knob left to decrease tilt tension.

**3** Back tilt lock adjustment (single position) - Rotate knob right to lock in position. Rotate knob left to unlock and free float.

**4** Foot ring height adjustment (for **-11DR** or **-11XDR**) - Press down on the plastic inner hub and lift the foot ring up to unlock. Adjust to desired position. To lock, press down on the outer foot reset until hub is in locked position.



**Contract Holder**

contract #: GS-28F-005CA

contractor: VIA INC