


**67C-SS** Quick adjust advanced synchro control with a seat depth adjustment user guide.



- 1** Seat height adjustment - Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.
- 2** Back tension adjustment - Rotate knob right to increase tilt tension. Rotate knob left to decrease tilt tension.
- 3** Back tilt lock adjustment (5 position) - Tilt the seat back to desired angle and twist slightly. To unlock, twist the other way, leaning back to unlock. The turn is smooth. All tilt lock angles can be reached within a single turn of the handle.
- 4** Seat depth adjustment (add optional **-SS**) - Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.



**Contract Holder**

contract #: GS-28F-005CA

contractor: VIA INC