

Body Balance Synchro #55C



Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

Seat Depth

Type: Pull paddle

Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.

4-Position Back Lock

Type: Pull paddle

To lock the chair in an upright position, turn the paddle up. To rock (free float), turn the paddle down. Lean back to click through the 4 different back positions.



< Watch our 55C
Online User Guide