


# Basic Conference Tilt #71C



## Single Position Back Lock

Type: Pull paddle

To lock the chair in an upright position, push the paddle in. To rock (free float), pull the paddle out.

## Back/Recline Tension

Type: Rotatable knob

Rotate knob right to increase tilt tension. Rotate knob left to decrease tilt tension. You can use your right or left hand based on your own comfort.

## Seat Height

Type: Pull paddle

Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.



< Watch our 71C  
Online User Guide