


55C Body balance synchro with seat depth adjustment.
Task & Conference seating.



1 Seat height adjustment - Adjust the seat height by lifting your weight out of the chair and pulling up on the paddle. Proper seat height is realized when the top of your legs are somewhat parallel to the floor.

2 Back tilt lock adjustment (4 position) - Rotate lever upward to unlock back tilt, lean back or forward to your desired position, rotate lever down to lock.

3 Seat depth adjustment - Pull up on paddle while shifting your weight forward to move your seat forward. Shift backward to move your seat back.



Contract Holder

contract #: GS-28F-005CA

contractor: VIA INC